

TROUBLE SHOOTING | FEATURES RUN CONTINUOUSLY

STEP 1 | Verify that the feature (s) and activation bollard (s) are set to auto in controller*;

VORTEX		CONTROL SETTINGS			
	Auto	Manual		Auto	Manual
FILTRATION PUMP	AUTO	off	PLAY PRODUCT PUMP	off	off
ACTIVATOR #1	AUTO	off	OPERATION TIME CLOCK	AUTO	off
ACTIVATOR #2	AUTO	off	PURGE	AUTO	off
ACTIVATOR #3	AUTO	off	RAIN DIVERTER	AUTO	off
			UV	AUTO	off
MAIN MENU		HELP	DYNAMIC BYPASS VALVE	AUTO	off

STEP 2 | Verify that the timer is set correctly*;

VORTEX		OPERATION TIME CLOCK			
SYSTEM TIME		06 / 04 / 15	10 : 55	5	DAY OF THE WEEK (1=SUNDAY)
PERIOD 1		PERIOD 2			
START TIME	STOP TIME	START TIME	STOP TIME		
07 : 00	21 : 00	00 : 00	00 : 00		
S M T W T F S		s m t w t f s			
PURGE START	DURATION (MIN)	MAX INACTIVE PERIOD (HRS)			
07 : 00	3	4			
MAIN MENU	HELP	RAIN DIVERTER TO TANK			

STEP 3 | Possible debris in solenoid or diaphragm issue or solenoid manually on.

NOTES: See valve maintenance

* Smart Touch Controller shown as reference



World leader in aquatic play solutions with over 6,000 installations worldwide
 vortex-intl.com • info@vortex-intl.com
 1.877.586.7839 (free USA/CND) • +1.514.694.3868 (Intl.)